


EA-3000



1-800-551-2406

www.eaglecompressor.com



EA-3000 PARTS LIST

ITEM #	QTY	DESCRIPTION	PART NUMBERS
01	12	Headbolt Screw	EA-3000-001
02	12	Flat washer	EA-3000-002
03	2	Cylinder Head	EA-3000-003
04	2	Head Gasket	EA-3000-004
05	4	Cylinder O-Ring	EA-3000-005
06	2	Crossover Tube	EA-3000-006
07	2	Valve Screw	EA-3000-007
08	2	Valve Limiter	EA-3000-008
09	4	Valve	EA-3000-009
10	2	Valve Plate	EA-3000-010
11	2	Valve clamp	EA-3000-011
12	2	Valve Screw	EA-3000-012
13	2	Cylinder to Valve Plate O-Ring	EA-3000-013
14	2	Cylinder	EA-3000-014
15	2	Piston Screw	EA-3000-015
16	2	Piston Cap	EA-3000-016
17	2	Teflon Ring	EA-3000-017
18	2	Connecting Rod	EA-3000-018
19	2	Fan Guard	EA-3000-019
20	2	Metal Snap Ring for Shaft	EA-3000-020
21	1	B Fan	EA-3000-021
22	4	Isolator	EA-3000-022
23	4	Fan Guard Screw	EA-3000-023
24	1	Left Crankcase	EA-3000-024
25	2	Screw	EA-3000-025
26	2	Bearing	EA-3000-026
27	1	Motor Rotor	EA-3000-027
28	4	Nut	EA-3000-028
29	1	Motor Stator	EA-3000-029
30	4	Motor Stator Washer	EA-3000-030
31	4	Through Bolt	EA-3000-031
32	4	Isolator Nut	EA-3000-032
33	2	Power Cord Isolator	EA-3000-033
34	1	Right Crankcase	EA-3000-034
35	4	Counter Weight Screw	EA-3000-035
36	2	Bearing	EA-3000-036
37	2	Counter Weight Crank	EA-3000-037
38	1	A Fan	EA-3000-038
39	1	Air Filter	EA-3000-039
40	1	Filter Pipe	EA-3000-040
41	1	Tank	EA-3000-041
42	1	Regulator	EA-3000-042
43	2	Pressure Gauge	EA-3000-043
44	2	Elbow	EA-3000-044
45	1	Quick Connect	EA-3000-045
46	2	Mounting Screw	EA-3000-046
47	1	Nylon Tube	EA-3000-047
48	1	Easy Valve Starter	EA-3000-048
49	1	Elbow	EA-3000-049
50	1	Discharge Tube	EA-3000-050
51	1	Check Valve	EA-3000-051
52	1	Pressure Switch	EA-3000-052
53	1	Quick Connect Fitting	EA-3000-053
54	2	Gasket	EA-3000-054
55	4	Manifold Plug	EA-3000-055
56	1	Safety Valve	EA-3000-056
57	1	Capacitor Cover	EA-3000-057
58	1	Capacitor Cover	EA-3000-058
59	2	Capacitor Cover Screw	EA-3000-059
60	2	Flat washer	EA-3000-060
61	1	Nylon Tube	EA-3000-061
62	2	Tube Insert	EA-3000-062
63	1	Ferrel Sleeve	EA-3000-063
64	1	Ferrel Nut	EA-3000-064
65	1	Ball Valve	EA-3000-065
66	4	Foot	EA-3000-066
67	4	Foot Bolt	EA-3000-067
68	1	Power Cord	EA-3000-068
69	2	Power Cord Isolator	EA-3000-069
70	1	Grip	EA-3000-070