


EA-4000



1-800-551-2406

www.eaglecompressor.com



EA-4000 PARTS LIST

ITEM #	QTY	DESCRIPTION	PART NUMBERS
01	12	Headbolt Screw	EA-4000-001
02	12	Flat washer	EA-4000-002
03	2	Cylinder Head	EA-4000-003
04	2	Head Gasket	EA-4000-004
05	4	O-Ring	EA-4000-005
06	2	Crossover Tube	EA-4000-006
07	2	Valve Screw	EA-4000-007
08	2	Valve Limiter	EA-4000-008
09	4	Valve	EA-4000-009
10	2	Valve Plate	EA-4000-010
11	2	Valve clamp	EA-4000-011
12	2	Valve Screw	EA-4000-012
13	2	Cylinder to Valve Plate O-Ring	EA-4000-013
14	2	Cylinder	EA-4000-014
15	2	Piston Screw	EA-4000-015
16	2	Valve Plate	EA-4000-016
17	2	Teflon Ring	EA-4000-017
18	2	Connecting Rod	EA-4000-018
19	2	Cylinder Extension	EA-4000-019
20	2	Fan Guard	EA-4000-020
21	2	Metal Snap Ring for Shaft	EA-4000-021
22	1	B Fan	EA-4000-022
23	4	Isolator	EA-4000-023
24	4	Fan Guard Screw	EA-4000-024
25	1	Left Crankcase	EA-4000-025
26	2	Screw	EA-4000-026
27	2	Bearing	EA-4000-027
28	1	Motor Rotor	EA-4000-028
29	4	Nut	EA-4000-029
30	1	Motor Stator	EA-4000-030
31	4	Motor Stator Washer	EA-4000-031
32	4	Through Bolt	EA-4000-032
33	4	Isolator Nut	EA-4000-033
34	2	Power Cord Isolator	EA-4000-034
35	1	Right Crankcase	EA-4000-035
36	4	Counter Weight Screw	EA-4000-036
37	2	Bearing	EA-4000-037
38	2	Counter Weight Crank	EA-4000-038
39	1	A Fan	EA-4000-039
40	1	Air Filter	EA-4000-040
41	1	Filter Pipe	EA-4000-041
42	1	Instrument Panel	EA-4000-042
43	2	Quick Connect	EA-4000-043
44	4	Mounting Screw	EA-4000-044
45	1	Pressure Gauge	EA-4000-045
46	1	Regulator Valve Stand	EA-4000-046
47	5	Manifold Plug	EA-4000-047
48	1	Pressure Gauge	EA-4000-048
49	1	Elbow	EA-4000-049
50	2	Nut	EA-4000-050
51	1	Nylon Tube	EA-4000-051
52	1	Ball Valve	EA-4000-052
53	2	Plug	EA-4000-053
54	4	Foot	EA-4000-054
55	2	Flat washer	EA-4000-055
56	4	Foot Bolt	EA-4000-056
57	2	Capacitor Cover Screw	EA-4000-057
58	2	Flat washer	EA-4000-058
59	1	Capacitor Cover	EA-4000-059
60	1	Capacitor	EA-4000-060
61	1	Twin Tank	EA-4000-061
62	1	Grip	EA-4000-062
63	1	Easy Valve Starter	EA-4000-063
64	1	Elbow	EA-4000-064
65	1	Discharge Tube	EA-4000-065
66	2	Gasket	EA-4000-066
67	1	Quick Connect Fitting Nut	EA-4000-067
68	1	Quick Connect Fitting	EA-4000-068
69	1	Straight Joint	EA-4000-069
70	1	Safety Valve	EA-4000-070
71	2	Power Cord Isolator	EA-4000-071
72	1	Pressure Switch	EA-4000-072
73	1	Check Valve	EA-4000-073
74	1	Ferrel Nut	EA-4000-074
75	1	Ferrel Sleeve	EA-4000-075
76	2	Lining	EA-4000-076
77	1	Nylon Tube	EA-4000-077
78	1	Power Cord	EA-4000-078