



MT3 Piggyback Shock Mounting and Adjustments

Mounting

Mount the shock with the shock body on the top (as shown in Photo 1)

Make sure the Noleen logo is legible to ensure shock is mounted in the proper position.

When bolting shocks to the frame and swingarm, make sure the thick side of the end eye spacer is facing the wheel (as shown in photo 2)

Photo 1



Adjusting

To adjust the preload of your shock spring loosen the set screw on the side of the preload adjuster (as shown in photo 3). Place your bike on the stand making sure the rear wheel is off the ground with no pressure on it. Rotate the spring using pin adjuster (as shown in photo 4), turn it clockwise to add preload or counter clockwise to reduce preload. Re-tighten set screw.

Photo 2



Photo 3



Photo 4



Starting Point

Setting free sag (spring compression due to weight of bike) varies based on bike year

Vintage 1/4 to 3/8 inch

Post Vintage 1/2 to 3/4 inch

We have already equipped your shocks with the correct springs for you. This is the only adjustment you need to take care of for yourself

If you have any questions please call 760 955 8757 or email us at info@noleenj6.com